


Quick Setup Guide


Unpack the machine and check the components




Read the Safety Guide first, then read this Quick Setup Guide for the correct installation procedure.

NOTE:
The USB cable is a standard accessory.


1 Remove the packing materials and install the toner cartridge



2 Load paper in the paper tray



3 Connect the power cord and turn on the machine




Printer LED Indications

Dimmed: ● Blinking: ☀ or ● ON: ● OFF: ○


	POWER OFF	READY	SLEEP DEEP SLEEP	WARMING UP COOLING DOWN	RECEIVING DATA DATA REMAINING	TONER LOW	REPLACE TONER	PAPER JAM	DRUM END SOON REPLACE DRUM
!	○	○	○	○	○	☀	☀	☀☀	☀☀☀
⦿	○	●	●	●	●	●	○	○	●
			Dimmed	1 second interval	0.5 second interval				

For more indications information, please visit our service support website: <http://www.fujixeroxprinters.com/>.




**NOTE:**

If the Fuji Xerox screen does not appear automatically, go to **Computer**.
(For Windows® 8: click the (File Explorer) icon on the taskbar, and then go to **Computer**.)
Double-click the CD-ROM icon, and then double-click **start.exe**.



Follow the on-screen instructions until the **Connection Type** screen appears.


Connection Type

For USB Connection

For Wireless Network Connection
We recommend preparing a USB cable to use temporarily during the wireless setup.

Follow the on-screen instructions to continue installation.

Finish

**Wireless Network Connection****[Recommended]**

Select this option if you have a USB cable to use temporarily for wireless setup.

Select this option if you do not have a USB cable.

Follow the on-screen instructions to continue installation.

Finish



Download the full driver and software package by visiting the Fuji Xerox website at <http://www.fujixeroxprinters.com/>.


After you download the driver and software package, follow the on-screen instructions until the **Connection Type** screen appears. Refer to **4A Configuration using the CD-ROM (Windows®)**.



If your wireless LAN access point/router supports automatic wireless (one-push) setup (WPS/AOSS™), you can set up your machine without using a computer.



Press the WPS or AOSS™ button on your wireless LAN access point/router.



Press and hold the **Wi-Fi/WPS** button on your machine for about 2 seconds. The **Wi-Fi/WPS** button will light up when connected.

Wireless setup is now complete.